



# FastCAM Software Series

---

## FastTRACK Reference Manual

---

*The World Standard in Profiling Software*



FASTTRACK®

---

Release issue 1  
2013

Published by

**FastCAM Inc**  
**8700 West Bryn Mawr,**  
**Suite 800 South**  
**Chicago IL 60631-3507 USA**  
**Telephone: (312) 715 1535**  
**Facsimile: (312) 715 1536**  
**Email: [fastcam@fastcam.com](mailto:fastcam@fastcam.com)**

**FastCAM Pty Ltd**  
**96 Canterbury Rd**  
**Middle Park 3206 Victoria**  
**Australia**  
**Telephone: (61)3 9699 9899**  
**Facsimile: (61)3 9699 7501**  
**Email: [fastcam@fastcam.com.au](mailto:fastcam@fastcam.com.au)**

**[www.fastcamusa.com](http://www.fastcamusa.com)**

Copyright © 2008  
All rights reserved

Information in this documentation is subject to change without notice.

All software and documentation is proprietary.

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of  
FastCAM Inc

The enclosed CD's / diskettes are serialized and may be used only by the registered user.  
It may not be resold or transferred without the consent of  
FastCAM Inc

FastCAM, FastNEST, FastPATH, FastPLOT, FastCUT, FastFRAME, FastSHAPES, FastTRACK,  
FastAIR, FastCOPY, FastPUNCH, FastRING, FastBEAM, FastPART and FastHULL are all  
registered trademarks of  
Fagan Microprocessor Systems Pty Ltd

Windows is a registered trademark of  
Microsoft Corporation in the United States and other countries

All other trademarks are acknowledged.



## Table of Contents

Conventions used in this manual .....	7
Representing section items .....	7
Representing keys .....	7
Representing a list of instructions .....	8
Representing important information .....	8
1. INTRODUCTION .....	10
2. GETTING STARTED .....	12
2.1 Hardware Requirements .....	12
2.2 Software Requirements .....	12
2.3 Installation .....	13
3. CONFIGURATION .....	20
3.1 Database Configuration .....	20
3.1.1 Setting up a new FastTRACK® database .....	20
3.1.2 Importing an existing FastTRACK® database .....	21
3.1.3 Configure FastTRACK® database on the server .....	22
3.2 FastTRACK® Configuration .....	28
3.2.1 Setup Branch Locations .....	29
3.2.2 Setup Users .....	31
3.2.3 Setup Suppliers .....	33
3.2.4 Setup Location .....	34
3.3 Options .....	36
3.3.1 File Export Path .....	37
3.3.2 FastCAM editor .....	38
3.3.3 Plate Name Prefix .....	38
3.3.4 Plate Name Suffix .....	39
3.3.5 Deletion Password .....	40
3.3.6 Printing .....	41
3.3.7 Colours .....	41
3.4 FastNEST® Configuration .....	42
3.5 Configure FastTRACK® Column Text .....	46
4. UPGRADING FROM PREVIOUS VERSIONS .....	48
4.1 Backing up your configuration file .....	48
4.2 Restoring your old database .....	49

5	USING FastTRACK® .....	52
5.1	A quick Overview of the screen: .....	52
5.2	Plate Browsing Tools .....	54
5.3	Adding a new rectangular plate.....	56
5.4	Deleting a Plate .....	58
5.5	Adding Remnant Plate .....	58
5.6	Edit Plate Data.....	60
5.7	Editing the Plate Shape .....	61
5.8	Rotating a plate.....	65
5.9	Moving Between Plates.....	66
5.9.1	Moving Back.....	66
5.9.2	Moving Forward .....	66
5.10	Searching for plates .....	67
5.10.1	Quick Search .....	67
5.10.2	Search First Plate .....	68
5.10.3	Search Last Plate.....	68
5.10.4	Search by Name .....	68
5.10.5	Search by Entry Number.....	68
5.10.6	Search for Today's Entry .....	68
5.11	Plate Management Tools .....	70
5.11.1	Inactive Small Plates.....	70
5.11.2	Update Areas.....	70
5.11.3	Locate Faults .....	70
5.11.4	Clear LOCKS.....	72
5.12	Printing .....	73
5.12.1	Current Plate .....	74
5.12.2	Show Cost .....	74
5.12.3	All Plates .....	74
5.12.4	Summary Report .....	74
5.12.5	Summary by Material (Totals).....	75
5.12.6	Paper Setup .....	75
5.12.7	Page Setup.....	76
5.13	FastTRACK® Reports.....	77
5.13.1	Audit Trails Report .....	77
5.13.2	Material Summary Report.....	80
	Email Support .....	81
	International Offices .....	84
	Index .....	85

## Conventions used in this manual

Throughout this manual, conventions have been used to help your understanding of the materials. The items that are emphasised include:

- Menu items
- Keys
- Mouse Buttons
- Screen-shots
- Cautions

### *Representing section items*

Each menu item is highlighted at the beginning of the description. The general form is:

#### **1.2.3 Edit plate information**

Where:

- The 1 is the chapter number
- The 2 is the section number
- The 3 is the sub section number

### *Representing keys*

When you need to type a specific key or click a particular button, it will be shown in bold lettering such as **ENTER**.



## ***Representing a list of instructions***

Step by step instructions are provided to the reader to guide them through detailed instructions on completing specific tasks, for example:

1. Go to the 'Files' menu.
2. Click on the 'Restore' option.
3. Select the appropriate file and hit 'Select'.

## ***Representing important information***

Important information has been presented in the following way to draw your attention, for example:



Please ensure you read this information before completing your task.

# CHAPTER

# 1

# 1. INTRODUCTION

FastTRACK<sup>®</sup> is a database management system for keeping a list of available plates. It also keeps track of off-cuts after processing and keeping your database up to date with live stock. This software is essential for business that needs to maintain a consistent record of their plates. It allows the plates information to be stored in a fashion that is easy to search, maintain and use. This allows the businesses to be more efficient and profitable.

FastTRACK<sup>®</sup> work closely with FastCAM<sup>®</sup> and FastNEST<sup>®</sup> software. FastCAM is used to edit CAM files which are inputs to plate list, and the plate list can be used in FastNEST<sup>®</sup> to keep track of available plates.

This manual is intended mainly for FastTRACK<sup>®</sup> users who want to understand how to use this software. It is also intended for I.T technicians who want to know how to setup the software for its users.

# CHAPTER

# 2

## 2. GETTING STARTED

### 2.1 *Hardware Requirements*

1. Any PC that is capable of running the Windows Operating systems listed below will be suitable for FastTRACK<sup>®</sup> version 3.
2. A USB or Parallel port dongle which comes with the FastCAM software.



If you are already using FastCAM software, then your existing software dongle can be used for FastTRACK<sup>®</sup>. If you would like to do this or are having trouble using your existing software dongle, then please contact FastCAM support.

### 2.2 *Software Requirements*

In order to operate FastTRACK<sup>®</sup> V3, you must be running one of the following versions of Windows operating system:

- Windows 98
- Windows NT
- Windows 2000
- Windows XP
- Windows Vista (32 bit)

## 2.3 Installation



*Before you install FastTRACK<sup>®</sup>, be aware that you need to have the Pervasive Database Client/Engine installed and working on your computer.*


With your computer turned on and ready for operation:

1. Insert the FastTRACK<sup>®</sup> installation CD into the CD tray.
2. Follow through with autorun. If your computer does not automatically run the setup application, please do the following:

Click on the **Start** button under windows, and then select '**Run**', type in the following into the window:

*[CDDRIVELETTER]:\Setup.exe*

Where **CDDRIVELETTER** is the letter representing your CD-ROM drive, e.g. D:\Setup.exe



**Figure 1: Initial Installation Screen**


3. Click on **Next** to proceed.



**Figure 2: License Agreement Screen**

4. Read through the License conditions carefully, when you are satisfied with the conditions, check the radio button on the left of “I accept the terms of the license agreement” by **LEFT** clicking on it. Then click **NEXT**.





**Figure 3: Selecting correct unit.**

5. This screen prompts you for the units FastTRACK<sup>®</sup> will be installed to operate with. After selecting your desired units, **LEFT** click on the **NEXT** button.
6. All the relevant files for FastTRACK<sup>®</sup> will now be installed onto your computer.
7. Install the FastLOC dongle:



*The FastTRACK<sup>®</sup> software requires a security dongle to be present on the computer in order for it to run. You will have either received a Parallel port or USB dongle with the software.*

- To connect a **parallel port** dongle, simply connect it to the LPT1 port at the back of your computer. If you already have a printer plugged into this port, then unplug the printer cable and attach the dongle into LPT1, then attach the printer cable onto the back of the dongle.



Figure 4: Parallel Port Dongle

- To connect a **USB** dongle, simply plug the key into one of the USB ports available.



Figure 5: USB dongle



*FastTRACK® will be installed into this folder by default:  
C:\Program Files\FastTRACK3\*



*You must be an administrator or at least have Read/write access to the FastTRACK<sup>®</sup> directory and your C:\ local directory for successful installation and setup.*

# CHAPTER

# 3

## 3. CONFIGURATION

### 3.1 Database Configuration

#### 3.1.1 Setting up a new FastTRACK® database



*Before starting the FastTRACK® configuration, you should already have the **Pervasive database** installed. The Pervasive database is necessary for the normal operation of FastTRACK®.*

1. Once you have successfully installed both FastTRACK® and the Pervasive database, you can then launch the FastTRACK® program by either **DOUBLE** clicking the icon on your desktop or by accessing it through the **PROGRAMS** menu from the Windows **START** button.

Upon starting FastTRACK® for the first time, if there is no FastTRACK® database setup on your computer the following message will appear:



**Figure 6: Database Warning Message**

2. Click on **Yes** to create a new database for FastTRACK®



A folder will be created on your computer located at `C:\PLATESDB`. This is where your database files will be stored.

- Use the default user ID and Password to log-in to FastTRACK® for the first time:



Figure 7: Login Screen

- Default User ID: **admin**
- Default Password: **ftrack**

### 3.1.2 Importing an existing FastTRACK® database

If you have existing FastTRACK® database files on your computer, you may be prompted to import them into the FastTRACK® database, as shown in the next diagram.




Figure 8: Importing old data file from previous versions

This message will take you through the process of importing old database files from previous version into version 3.

1. **LEFT** click the **YES** button to begin database import.
2. Scroll and find the desired branch, then **LEFT** click on the branch that the plates from the old database will be tagged to belong to.



Figure 9: Selecting branch information

3. **LEFT** click the **OK** button.
4. A progress bar will be shown to give you feedback on how many plates have been successfully added into the database.
5. **LEFT** click the **OK** button to finish importing plates into the database.


### 3.1.3 Configure FastTRACK® database on the server

In the case where there are multiple users for the FastTRACK® program, a central database must be set up. This database is usually being installed on the server computer, but can also be set up on any single PC within the network.

This section will explain the procedure for setting up pervasive database on the server, and configure the host PC to run FastTRACK<sup>®</sup> using the FastTRACK<sup>®</sup> database on the server.


1. To install your FastTRACK<sup>®</sup> database on the server, you must already have Pervasive Database Engine installed.
2. The entire FastTRACK<sup>®</sup> database is contained in the 'platesdb' folder, if you have a backup copy of your old database, copy the 'platesdb' folder onto the server. A suitable location would be directly under C drive.
3. If you do not have a copy of the FastTRACK<sup>®</sup> database, please follow section 3.1.1 to create a new database on the **HOST PC**, and then copy the 'platesdb' folder onto the server.
4. Create DNS for the FastTRACK<sup>®</sup> database on the server by completing the following steps:
  - a) Go to '**START**' -> '**CONTROL PANEL**'.
  - b) While the control panel is in 'Classic View', click on '**Administrative Tools**'.
  - c) Click on '**Data Sources (ODBC)**'.
  - d) Select the '**System DSN**' tab.
  - e) Click on '**Add**' button to create a new Database Source Name (DSN).
  - f) Under a list of drivers, scroll down until you find '**Pervasive ODBC Engine Interface**'. Single click to highlight this driver and click on '**Finish**' to add this driver.





**Figure 10: Creating a FastTRACK® database source.**

- g) Under the '**Pervasive ODBC Engine DSN Setup**' window, enter '**platesdb**' for 'Data Source Name'.
- h) Click '**Create**' button to bring up the '**Create Database**' window.
- i) Type in '**platesdb**' for the **Database Name**.



**Figure 11: Creating database source by specifying the database location.**

- j) Click on '**Browse**' button for dictionary settings to find the folder containing the database files.
  - k) Locate the '**platesdb**' folder where you have copied.
  - l) Exit from all the setup windows.
5. Delete '**platesdb**' folder if it exists on the client computer.
  6. Create a DNS on the client computer to connect to the database on the server:
    - a) Go to '**START**' -> '**CONTROL PANEL**'.
    - b) While the control panel is in 'Classic View', click on '**Administrative Tools**'.
    - c) Click on 'Data Sources (ODBC)'.

- d) Select the 'System DSN' tab.
- e) Click on 'Add' button to create a new Database Source Name (DSN).
- f) Under a list of drivers, scroll down until you find '**Pervasive ODBC Client Interface**'. Single click to highlight this driver and click on '**Finish**' to add this driver.



If you have version 8 of Pervasive Database Engine or earlier, you will need to select 'Pervasive ODBC Engine Interface' instead.

**Figure 12: Creating database source connection to the server.**

- g) Type in '**platesdb**' under '**Data Source Name**'.
- h) Type in either the IP address or the server name under '**Address**' field.

- i) Click on '**Get DSN List**' button to obtain a list of DSNs on the server computer.
- j) Select '**platesdb**' from the list and click 'OK' button'.

Repeat steps 4 to 6 to setup other PCs which use the FastTRACK<sup>®</sup> database.

## 3.2 FastTRACK® Configuration

FastTRACK® After creating a new database or importing an old version, the next step is to set-up FastTRACK® by using the “FastTRACK® initial configuration” window.



**Figure 13: Initial Configuration Menu**

The initial configuration will take you through the following four configurations:

1. Add Branch Locations
2. Add Users
3. Add Suppliers
4. Add Locations



*For FastTRACK<sup>®</sup> to operate, you must add at least one Branch Location and one User from the initial configuration.*


### 3.2.1 Setup Branch Locations

A **branch location** is simply a description of your offices/warehouses. For large organisations, adding branch information is particularly important to ensure plates can easily be identified and found.

Typically the first branch to be entered is the primary processing plant. This may be your current location.

*Follow the steps below to add branch locations:*

1. **LEFT** click on the **Start** button on the **Add Branch Locations** row.
2. The branch window will appear, and it is initially empty. **LEFT** click on the **Add** button to add new branches.
3. A sub-window will appear and prompt you for a **BranchID** and **Branch Name**. Enter according to your company's convention (See the diagram for example). Click **OK** when complete.
4. In the case where mistakes have been made, **LEFT** click on an existing branch from the 'branches' window and **LEFT** click on the **DELETE** button to remove the branch.
5. Repeat from Step 1 to add more branches.



**Figure 14: Entering Branch Details.**

6. When you have completed adding branches, **LEFT** click on the **Exit** button to return to the **Initial Configuration** window.



*The **Done** check boxes have been provided to the user to mark off completed configuration.*

### 3.2.2 Setup Users

FastTRACK<sup>®</sup> has four different classes of users with different levels of access privileges for the software. The description of each type of user's privileges and their options are as follows:


- **Database Manager**  
This type of user has the highest level of privileges. A database manager can perform administration tasks such as manage users, add locations as well as manipulate data in the database.
- **Manager**  
Managers have all the administration rights such as setting up branches, users, location and supplier. They also have access to data within the database.
- **Estimator**  
Estimators are the most common user in FastTRACK<sup>®</sup>. This group of users can manipulate plate data. However they **DO NOT** have any administration privileges including manage **users, suppliers and branches**. However they do have privileges to manage **locations**.
- **Browser**  
A browser does not have any administration privileges nor do they have any rights to edit data. Browsers only have rights to *view* and *print* data, but may not make any modifications.



*An estimator is the standard user for FastTRACK<sup>®</sup>. You **MUST** create an account as an estimator in order to use FastTRACK<sup>®</sup>. Please follow these steps to set up your users using the default administrator account.*



1. **LEFT** click on the **Start** button in the **Users** setup.
2. A **User Registration** window becomes available, initially empty. **LEFT** click on the **Add** button and the **Enter User Information** window appears.
3. Under **User Details**, **LEFT** click to select the **Estimator** class.
4. Enter a login in the **Estimator ID** section: note the box is yellow indicating that you have to type in this information to proceed.
5. OPTIONAL: Enter a password for this user in the **Password** section.
6. OPTIONAL: Enter the name of the user in the **Name** section.
7. **LEFT** click **Save** after double checking all the information has been entered correctly and the password has been remembered.



The image shows a dialog box titled "Enter User Information...". Inside, there is a section titled "User Details..." with four radio button options: "DbMgr", "Manager", "Estimator" (which is selected), and "Browser". Below these are three input fields: "Estimator ID" (highlighted in yellow), "Password", and "Name". The "Estimator ID" field has a note "(max. 12 chars)" below it. At the bottom of the dialog are "Save" and "Cancel" buttons.

**Figure 15: Setting up new users**

8. Repeat from step 1 to add more users, take care in choosing the correct user class.

9. **LEFT** click the **EXIT** button to return to the **Initial Configuration** window.




*You must have at least ONE administrator account, and the default admin account can be deleted only when you have another admin account.*

### 3.2.3 Setup Suppliers

Suppliers are the providers for the plate stock, this information is essential to keep track of where the plates are originally bought from, however setting up supplier is optional and FastTRACK<sup>®</sup> will function normally without having any supplier being setup.

To set-up suppliers:

1. **LEFT** click on the start button on the Add Supplier row in the Initial Configuration Window.
2. **LEFT** click Add button to add new branch.
3. Move your cursor under the supplier column and **SINGLE** click in the text box. Enter the name of your supplier, and **SINGLE** click elsewhere in the window to finish editing.
4. In the case where you have made a mistake, **DOUBLE** click on the text-box to edit the supplier.
5. Repeat step 2 to 4 to add more supplier in the database.
6. **LEFT** click **EXIT** button to finish adding supplier.



**Figure 16: Adding a supplier.**



*Only database manager and manager have the privileges to modify the suppliers.*


### 3.2.4 Setup Location

Locations provide the physical housing locations for the plate stock. These can be changed by all users except browsers.

To add a new location:

1. **LEFT** click on the start button on the **Add Locations** row in the **Initial Configuration Window**.
2. **LEFT** click **Add** button to add new location.

3. Move your cursor under the location column and **SINGLE** click in the text box. Enter the name of your supplier, and **SINGLE** click elsewhere in the window to finish editing.
4. In the case where you have made a mistake, **DOUBLE** click on the text-box to edit the location field.
5. Repeat step 2 to 4 to add more locations in the database.
7. **LEFT** click **EXIT** button to finish adding locations.



**Figure 17: Adding a location.**

### 3.3 Options

The final step in configuration is to set up *various* options under the 'Configuration **Menu**'.

To begin options setup:

Choose **Configuration => Options from the menu.**





Figure 18: Option Setup Screen.

### 3.3.1 File Export Path

FastTRACK<sup>®</sup> allows the users to export plates as CAM files, and this option specifies the location where the CAM files are going to be exported. The procedure for setting up an export path is:



**Figure 19: File Export Path Set-up.**

1. **LEFT** click on the “...” **Browse** button at the end of the “**CAM File Path:**” entry.
2. An explorer window will become available, browse to the folder where you want the files to be exported to.
3. **LEFT** click on the **OK** button to return to the ‘Options’ window.

### 3.3.2 FastCAM editor

This option allows the user to specify the path where the FastCAM editor is located; the default location is *C:\Program Files\FastCAM*. If the program is located somewhere else, then you must point to the correct directory.

To set up FastCAM drawing editor to work in conjunction with FastTRACK<sup>®</sup>:

1. **LEFT** click on the “...” **Browse** button at the end of the CAM FILE Path entry.
2. An explorer will become available, browse to the folder where the FastCAM is installed.
3. **LEFT** click on the OK button to return to the ‘Options’ window.




Figure 20: FastCAM File Path Directory Setup.


### 3.3.3 Plate Name Prefix

This option allows the user to specify the prefix for the plate name. By default, it is set to *By Material*. Example of a plate name utilizing this convention is *GR3500001*, where the plate is a Mild-Steel with a grade of GR350.

However you may choose the plate name to start with a specific name or string by selecting on *By Input*. You’ll be required to enter a string in a text-box next to the ‘By Input’ radio button, and every new plate you create will start with this string.

Example of a plate utilizing this convention is *UNIQUE001*, where the string ‘UNIQUE’ is user’s input, and all subsequent new plates will be named as *UNIQUE002*, *UNIQUE003*, etc.

Alternatively, you can choose not to have a prefix by selecting the *By Manual Input* checkbox. The users will be able to enter their own plate name when creating a new plate.



The image shows a dialog box titled "Prefix" with a light gray background. It contains three radio button options: "By Material" (which is selected), "By Manual Input", and "By Input". To the right of the "By Input" option is a small, empty rectangular text input field.

**Figure 21: Choose plate name prefix option**



*The allowed key characters for the file name include alpha and numerical characters.*

### 3.3.4 Plate Name Suffix

Similarly you may choose to specify a unique ending for the plate name by selecting either by *Record number*, *None* or *By Input*. The default selection is **record number**.

When ‘**By Material**’ or ‘**By Input**’ is selected for the prefix option, the ‘**Record number**’ is automatically selected and can’t be changed to ‘**None**’ or ‘**By Input**’.



Only when 'By manual Input' is selected for the prefix, the user will have the option to select one of the three suffix options.

When '**By Record Number**' is selected, the suffix of the plate name will be automatically incremented. Selecting '**By input**' will allow the user to have a specific ending for the plate name, such as 'PR01ENDING', where '**ENDING**' is the defined suffix. Finally selecting '**None**' will disable the suffix option.

Figure 22: Setting Plate Name's Suffix.



*The **none** or **By Input** option is only enabled when you select **By manual input** in the Prefix area.*

### 3.3.5 Deletion Password

A *Deletion password* is set to allow *estimators* to delete plates within the database. Otherwise an estimator will not be able to delete any plates. The password has maximum length of 8 characters.


Figure 23: Set Plate Deletion Password.



*Only **Administrator** and **Managers** have the ability to set the **Deletion Password**.*

### 3.3.6 Printing

Enabling this option will allow the user to see the Plate cost on printouts.




**Figure 24: Printing Option**

### 3.3.7 Colours

This option enables the users to customise the colours displayed in the drawing area of the FastTRACK<sup>®</sup> screen.

To change the colour scheme for the background, drawing or dimensions, simply **DOUBLE CLICK** on the coloured area and select a desired colour from the palette.



**Figure 25: Colours Setup.**

### 3.4 *FastNEST*<sup>®</sup> Configuration

FastNEST<sup>®</sup> works in conjunction with FastTRACK<sup>®</sup>. It has the ability to utilise the plates inside the FastTRACK<sup>®</sup> database for nesting. The plate information can be automatically updated once nesting is complete. This keeps the plate database consistent and also makes the nesting job easier.

In order to use the plate list from the FastTRACK<sup>®</sup> database inside FastNEST<sup>®</sup>, you must first enable this option, and this is achieved by the following steps:

1. Find the *SETUP.DAT* file inside C:\Program Files\FastCAM directory. If you have multiple machines set up, then browse to that directory. This is usually located under C:\Program Files\FastCAM\machines\machineName\...
2. Open the *SETUP.DAT* file with Notepad or a similar text editor, type in “*FASTTRACK,1*” at the bottom as shown in the figure below.
3. Save and close the file.





Figure 26: Enable FastTRACK<sup>®</sup> for FastNEST<sup>®</sup> inside SETUP.DAT

Once this option is enabled, the FastTRACK® database can then be used from FastNEST® for nesting as shown in below:



**Figure 27: Using plate list inside FastNEST®**

To use a plate from the FastTRACK® database within FastNEST®:


1. Click the **Change Plate** button from the toolbar.
2. Select the '**FastTRACK® database**' option button.
3. Search your plate by specifying the thickness, material type, grade (if available) and branch (if necessary). And then click the **SEARCH** button.

4. **LEFT** single click to select the appropriate plate from the list, and then click on the **DONE** button to use the plate inside FastNEST<sup>®</sup>.
5. FastNEST<sup>®</sup> now uses the dimensions of the selected plate for nesting. Finish your nesting and output the code. (please refer to FastNEST<sup>®</sup> manual on nesting).
6. If you have made a trim on plate and decided to make the remaining portion as a remnant plate. You'll encounter the following message when outputting the NC code.



**Figure 28: Trimming for remnant plate**

Click on **YES** will allow a daughter plate to be created automatically inside the database, and the following window will appear. Click on **NO** to take no action.



**Figure 29: Creating daughter plate from plate trim**



*The daughter plate is the remaining plate after the trim. Note that the daughter plate is named after the original plate with '-A' in the end.*

7. If you have not made a plate trim during nesting. A message will appear and ask you to make the plate **'Inactive'**. Click **'YES'** to mark the plate inactive inside the FastTRACK<sup>®</sup> database, or click **'NO'** and the plate will remain **'ACTIVE'**.



### 3.5 Configure FastTRACK® Column Text

FastTRACK® allows the users to customise the column names according to their own conventions. For example, instead of having the **Supplier** as one of the fields in the database table, the administrator has the option to replace it with a customised value. The fields that can be changed are shown in the diagram below under the column **Default Value**, and these values can be changed by entering a value on the right hand side text-box called Custom Value.




Figure 30: Configure FastTRACK® column text

# CHAPTER

# 4



## 4 UPGRADING FROM PREVIOUS VERSIONS

If you are upgrading from previous versions of FastTRACK<sup>®</sup>, then please follow these procedures.

### 4.1 **Backup your configuration file**

It is essential that important files be backed up before restoring your database.

The important file for FastTRACK<sup>®</sup> is the “Material.DAT” file which contains a list of all the Materials and associated data that all the plates use.

Steps to follow for back and restore of this file are:

1. Make a copy of the ‘**Material.DAT**’ file from your FastTRACK<sup>®</sup> directory. This is usually located in the “**C:\Program Files\FastTRACK\**” directory.
2. Run the FastTRACK<sup>®</sup> version 3 installation.
3. Once the installation is complete, copy the ‘**Material.DAT**’ file into your ‘**C:\Program Files\FastTRACK3**’ directory and overwrite if required.

## 4.2 Restoring your old database




*Make sure you have logged in to FastTRACK® as an administrator, only administrators have the privileges to import an old database.*



*Make sure you have either 'platebase.dat' or 'plate.dat' located inside the directory where all your CAM files are located. This is essential for importing the data successfully into FastTRACK®.*

1. Run FastTRACK® 3 by selecting **START -> All Programs -> FastTRACK® -> FastTRACK® v3** or by clicking on the toolbar menu on your desktop.
2. Choose **FILE -> IMPORT**.
3. Select either Version1.0 or Version2.0 depending on your previous version.



**Figure 31: Import Existing Database**

4. Database restoration will be completed automatically.




Figure 32: Importing plates in process

# CHAPTER

# 5

## 5 USING FastTRACK®

### 5.1 *A quick Overview of the screen:*

#### a. **File Menu**

You can access the full range of features offered by FastTRACK® in these menus. Each of their functions will be discussed in depth in the later parts of this manual.

#### b. **Toolbar menus**

Some commonly used and important features can be accessed via these graphical shortcuts. These will be discussed in later sections.

#### c. **Plate Database List**

A selected list of plates in the database that have matched the parameters set in various search panels. Each plate shown has a range of its attribute shown as well for convenience.

**LEFT** clicking on a plate's row will select that plate.

**LEFT** clicking on the column names will sort the displayed plates by that field in ascending order.




Figure 33: Options Setup Menu.

**d. Plate search filters**

A panel where you can choose to filter the list based on material, thickness, and status of the plates.

**e. Plate information**

Displays dimensional properties about the plate, these are not editable.

**f. Selected plate Preview.**

This shows the shape of the plate, and can have options enabled to show the original plate or view the plate file as a text code.

## 5.2 Plate Browsing Tools

It is important to be familiar with the basic tools for plate browsing, reviewing and manipulation.

There are 3 windows that the users need to be familiar with:

### 1. The plate list


Please see section 5.1 point C for description.

### 2. Plate Selection Window

This window allows the user to search and narrow down the plates displayed in the plate-list using appropriate filters. These filters can be used individually or concurrently. Several *filters* are available to use and these are:

- *Branch*
- *Material and Grade*
- *Thickness range*
- *Status of the Plate (whether it's active or not)*

Here is an example of using these options to populate all active plates with a thickness of 20 mm for Stainless Steel SS304:



The image shows a software interface titled "Plate Selection". It contains several input fields and checkboxes. The "Branch" field is a dropdown menu with "1" selected. The "Material and Grade" field is a dropdown menu with "Stainless, SS430" selected. The "Thickness" field has a checked checkbox, followed by two input boxes, both containing "20", with "mm" labels on either side and a right-pointing arrow between them. At the bottom left, there is a checked checkbox for "Only Active Plates". At the bottom right, there is a "Select" button with a dashed border.

Figure 34: Plate Selection Panel.

1. Select 'ALL' from the **branch** drop-down box.
2. Select 'Stainless Steel SS304' from the **Material** drop-down box.
3. Check the '**Thickness**' box and input 20 in both text boxes.
4. Check the '**Only Active Plate**' box.
5. Click '**SELECT**' button to populate the filtered results.

### 3. Plate Information/Image Preview Window

This window gives the preview of a selected plate. The dimensional information and cost information is displayed on the bottom left window, whereas the plate image is displayed on the bottom right window.

There are two additional check-box options available as shown below:

The screenshot shows a 'Plate Information' panel with the following fields and options:


- Original Size: [ ] × [ ] mm
- Current Size: [ 3000 ] × [ 1000 ] mm
- Remaining: [ ] %
- Cost: [ \$487.49 ]
- Checkboxes:  Show Text,  Show original plate

**Figure 35: Plate Information Panel.**


- *Show Text*  
This will display the selected plate in terms of text rather than the image. A plate is described in terms of a text inside the database, this option is useful for advanced users to check the finer details of the particular plate.
- *Show Original Plate*  
This will display a red outline for remnant plates that show the original shape of the plate.



### 5.3 Adding a new rectangular plate

To add a new rectangular plate into the database, choose **EDIT -> ADD NEW -> RECTANGULAR PLATE** or click the ‘add new rectangular plate’ button  from the toolbar.

The following window will appear:



**Add new Rectangular plate information...**

Entry number:

Plate File Name:

Plate Size: X  Y

Branch:

Material:

Thickness:  mm

Density:  kg/m<sup>3</sup>

Area:  m<sup>2</sup>

Weight:  kg

Heat number:

Mill number:

Order Number:

Supplier:

Cost:  \$/kg

Location:

Comment:

Figure 36: Filling in the rectangular plate information.



*The Fields that are coloured Yellow are mandatory fields. These must be completed before the plate can be added into the database.*

*A quick breakdown of the fields:*

<b><i>Attribute</i></b>	<b><i>Description</i></b>
Plate size x, y	Size of the plate in length and width
Branch	The branch where this plate is held
Material	The material of the plate, list taken from material.dat file
Thickness	The thickness of the plate
Density	Auto filled from material.dat
Area	Auto calculated from plate perimeter dimensions
Weight	Auto calculated from area and density
Heat number	An identifier for this plate, title customizable
Mill number	An identifier for this plate, title customizable
Order number	An identifier for this plate, title customizable
Supplier	Supplier for plate, list configurable via admin
Cost	Cost of the material per kilogram
Location	Storage location for plate, list configurable via admin
Comment	Addition comments

## 5.4 Deleting a Plate

To delete a plate from the plate list, you must have your plate selected from the plate list window. Then choose EDIT -> **DELETE**.



*If you do not have a **Delete Password** set by your database manager, you will see the following error message.*




Figure 37: Error message caused by not having a 'Delete Password'.

Please contact your administrator to set a password to enable plate deletion option. To enable plate deletion option, please refer to section 3.3.5 of this manual.

## 5.5 Adding Remnant Plate

Plates can be added into the database from existing CAM files. This is especially useful for adding existing remnant plate shapes into the FastTRACK® database. FastTRACK®

*To import a plate from an existing CAM file:*

Choose **EDIT ->ADD NEW-> CAM FILE** or click on the *Add new remnant plate* button  .

This brings up a similar window to the ‘**add new rectangular plate**’.

1. Fill in the details of the plate (Notice the dimension text boxes have been disabled, this will be determined when the specific CAM files has been imported).
2. Click **Browse** button to locate the CAM file to be imported.
3. Click **Save** to import the new remnant plate.

**Add new CAM plate information...**

Entry number:

Plate File Name:

Plate Size: X  Y

Branch:

Material:

Thickness:  mm

Density:  kg/m3

Area:  m2

Weight:  kg

Heat number:

Mill number:

Order Number:

Supplier:

Cost:  \$/kg

Location:


Comment:

**Figure 38: Adding new plate from existing CAM files.**

## 5.6 Edit Plate Data

To edit the parameters of a plate:

Choose **EDIT -> EDIT Plate Data** or click on the Edit Plate Data button from the toolbar.



The screenshot shows a dialog box titled "Edit plate data ..." with a close button (X) in the top right corner. The dialog contains the following fields and controls:

- Entry number:** Text input field containing "5976".
- Plate File Name:** Text input field containing "GR25005976" and a "Browse" button to its right.
- Plate Size:** Two text input fields labeled "X" and "Y" containing "3000" and "9000" respectively.
- Branch:** A dropdown menu showing "1".
- Material:** A dropdown menu showing "Mild-Steel , GR250".
- Thickness:** Text input field containing "8" with the unit "mm" to its right.
- Density:** Text input field containing "7850" with the unit "kg/m3" to its right.
- Area:** Text input field containing "27" with the unit "m2" to its right.
- Weight:** Text input field containing "1695.6" with the unit "kg" to its right.
- Heat number:** Empty text input field.
- Mill number:** Empty text input field.
- Order Number:** Text input field containing "5158-5159".
- Supplier:** A dropdown menu.
- Cost:** Text input field containing "0.9" with the unit "\$/kg" to its right.
- Location:** A dropdown menu with an ellipsis button "..." to its right.
- Comment:** Empty text input field.

At the bottom of the dialog are "Save" and "Cancel" buttons.


Figure 39: Editing plate information.




This function allows you to modify information for the selected Plate only. The fields grayed out in the diagram **CANNOT** be changed:

## 5.7 Editing the Plate Shape

The shape of the plate can be modified inside FastTRACK® by calling upon the FastCAM® Drawing Editor.

1. While having your plate selected, choose **EDIT -> EDIT PLATE SHAPE** or click the **edit plate** shape button  from the toolbar.
2. The FastCAM® application will load up as shown below with the selected plate.
3. Edit the plate and make all necessary modifications. *Users can use various editing tools such as **Corner Notch**, **Chamfer** or **Trim** to modify the existing plate. See FastCAM® Manual.*
4. Once you have finished editing the plate, exit the program by choosing **FILES -> EXIT**.



**Figure 40: Using FastCAM® to modify the plate shape.**




Figure 41: Plate shape after editing..

5. A window will appear asking the user whether the changes can be updated into the FastTRACK® database.
6. Click **YES** to save the changes made. FastCAM® will then close and the following question will appear in FastTRACK®:





**Figure 42: Create daughter plate.**

This message allows the users to create an ***IDENTICAL RECORD*** in the database, but with a plate of a new name. The original plate will then be marked as ***INACTIVE***.

***YES*** - A new plate will be created, and it is named with ‘-A’ appended to the old plate name. E.g. if the old file name is called **GR25004**, then the daughter plate will be named as ‘**GR25004-A**’. The old plate will be marked as ‘**INACTIVE**’.

***NO*** – Plate modifications will only be applied to the original plate, and no daughter plate will be created.



Check the ***Show Original Plate*** box in the ***Plate information*** section and you’ll then be able to see a red outline in the plate display that represents the original plate shape when it was first entered into the database.

## 5.8 *Rotating a plate*


To rotate a plate **clockwise** by 90 degrees, click the Rotate Plate button




on the toolbar. The update to the plate is immediate and the change is saved to database automatically.

## 5.9 *Moving Between Plates*

### 5.9.1 Moving Back

By clicking on this icon  the 'previous' plate will be selected in the current list. This translates to moving up one row in the list of plates. Alternatively, you can also choose **SEARCH -> PREVIOUS** to go the previous plate.

### 5.9.2 Moving Forward

By clicking on this icon  the 'previous' plate will be selected in the current list. This translates to moving down one row in the list of plates. Alternatively, you can also choose **SEARCH -> NEXT** to go to the next plate.

## 5.10 Searching for plates

There are many search options available in FastTRACK® to allow the users to search for a particular plate within the database.

### 5.10.1 Quick Search


**LEFT** clicking on the search icon  will bring up the **Quick Search** Window, or alternatively you can choose **Search -> Quick Search**. Choose **ONE** of the available parameters to search for particular plates. **LEFT** click on the **Search** button will display the results inside the **Plate List** window. The user can then perform functions such as printing reports and editing for these plates.



Figure 43: Quick search window

**LEFT** clicking on **Only Active Plates** will allow users to view the *ACTIVE* plates only.

### **5.10.2 Search First Plate**

This option allows the user to jump to the first plate in the list. To go to the first plate in the list, choose **SEARCH -> FIRST**.

### **5.10.3 Search Last Plate**

This option allows the user to jump to the last plate in the list. To go to the last plate in the list, choose **SEARCH -> LAST**.

### **5.10.4 Search by Name**

This option allows the user to search a particular plate by its filename. To search a plate by its file-name, choose **SEARCH -> By Name**.

### **5.10.5 Search by Entry Number**

If you know the entry number of the plate you are looking for, this option allows you to find that particular entry. To search for that particular entry, choose **SEARCH -> By Entry Number**.

### **5.10.6 Search for Today's Entry**

This option allows you to search for plates that have been created or modified on that particular day. To search for today's entries, choose **SEARCH -> Today**.

## 5.11 *Plate Management Tools*

FastTRACK® provides several tools which helps the user to keep the plate database consistent, fault-free and up-to-date.

### 5.11.1 Inactive Small Plates

This option allows the users to make all plates inside the database **INACTIVE** for plates smaller than a specified area (in square metres). It is accessed by choosing **CONFIGURATION -> INACTIVATE SMALL PLATES**.

### 5.11.2 Update Areas


This utility function allows the user to check the plate area field against the dimensions defined in the CAM file. Sometimes discrepancy can occur between the area recorded in the database and the dimensions defined in the CAM file. And this option is accessed by choosing **CONFIGURATION -> UPDATE AREAS**.

### 5.11.3 Locate Faults

This function allows the users to check for incorrect and inconsistent records in the database given a maximum area and cost. It will traverse through the active plate list and examine whether the area matches the specified dimensions and cost.

To use this function, choose **CONFIGURATIONS -> LOCATE FAULTS**.


Firstly you'll be prompted with the following message:



**Figure 44: Check for inactive plates.**


Click **YES** to check ALL plates, which include ACTIVE and INACTIVE plates. And click **NO** to check for ACTIVE plates only.

Next you'll be prompted to enter a maximum area and cost as shown in the diagram below:



**Figure 45: Specifying maximum area and cost for 'Locate Faults'.**

Once the maximum area and cost has been specified, the program will traverse through the active plate list and look for faults. A summary of the search will be given at the end of the search as shown below:



**Figure 46: Search results of locate faults.**



Click ‘**OK**’ button and a list of plate with faults will be displayed in the **plate list window**. You may now manually check and correct these faults.

#### 5.11.4 Clear LOCKS

When multiple users are using FastTRACK® at the same time, ‘locks’ will be set on particular records that are currently being used. This is to prevent simultaneous changes by different users, and each record has its own lock.

Sometimes these ‘locks’ have been left behind on a particular plate, and causing another user not having access to this particular plate. In this case, locks must be removed to enable access to all other users. The database manager and manager have the privileges to clear all locks by using ‘Clear Locks’ function.


To clear locks on all records, simply choose ‘**Configurations**’ -> ‘**Clear Locks**’. A warning message will then appear, clicking ‘**YES**’ to reset all locks.




*Only **Database Manager** and **Manager** have privileges to this function. Please ensure that no active users are logged in when you are performing this function.*

## 5.12 Printing

The printing functionality allows the users to print stock reports for both the *CURRENT* and *ALL AVAILABLE* plates. These reports can provide statistics on the cost and availability of the remaining stock.

To print a report choose **FILE -> PRINT** or click the print button  from the toolbar.



**Figure 47: Printing a report.**

### 5.12.1 Current Plate

To only print the currently selected plate, click on this option button. On the left a print preview of the plate shape and it's details will be shown.

### 5.12.2 Show Cost

This option will allow the user to see the cost of the material in the printed report. The display of cost can also be set as a default under settings in the configuration. To enable this option, choose **Configurations** -> **Option**, and check the 'show cost on print-out' radio box.

### 5.12.3 All Plates

To print the range of plates that are defined from the Plate Selection on the main FastTRACK® window, click on this radio button. You can then browse through the print preview to view the each individual plate shape and plate parameters by using the preview buttons at the bottom of the preview window.

### 5.12.4 Summary Report

Selecting this option will print a report containing list of plates that have been selected from the plate list window. It gives details of each plate as well as the total weight and cost.

**Plate Summary : Tuesday, 18 September 2007 09:49:33**  
**Material: Mild-Steel , GR250**

Entrynumber	FileName	Material	Grade	Thickness	Area	Updatedate	Weight	Cost
2	GR252	Mild-Steel	GR250	10	50	04/09/2007	3925	.9
1	GR201	Mild-Steel	GR200	10	3	04/09/2007	235.5	.9
3	GR203	Mild-Steel	GR200	10	12	04/09/2007	942	.9
4	BIS3000206	Mild-Steel	GR200	6	2.5	04/09/2007	117.8	.9

**4 Plates in total for Mild-Steel , GR250 Materials.**  
**Total weight 5220kg**  
**Total cost \$4698.225**

Figure 48: An example report showing all available plates.

### 5.12.5 Summary by Material (Totals)

Selecting this option will print all plates in the database grouped by their Material and Grade, displaying total weight and cost per grade.

**PLATE SUMMARY by Material**  
Tuesday, 18 September 2007 10:02:07

Number of Plates	Material	Weight (kg)	Cost
3	Mild-Steel , GR200	1,295.25	\$1,165.73
1	Mild-Steel , GR250	3,925.00	\$3,532.50
<b>Total Plates</b>	<b>Total Weight (kg)</b>	<b>Total Cost</b>	
4	5,220.25	\$4,698.23	

Figure 49: An example report organised by different materials.

### 5.12.6 Paper Setup

For basic page setup you can select the orientation of the print, and the printer to be used from the dropdown box.

### **5.12.7 Page Setup**

For advanced paper setup click on page setup and it will bring up the advance setup tab for the selected printer.

## 5.13 **FastTRACK® Reports**

There are two types of reports that FastTRACK® can generate which provides key information on the usage and overview of the plate stock.

### 5.13.1 **Audit Trails Report**

This type of report provides a history on the usage of the plates by all users. It is useful for estimator to find out who, when and what has been changed from the plate list.

To generate the Audit report, Choose **Reports** -> **Audit Trails from the menu.**




Figure 50: Audit Trail Report.

The user can either browse through the entries one by one or filter the entry results based on one of the four selection criteria. To narrow the plate selection, click on **Edit** button from the **Selection** panel to bring up the window shown below.

**Audit Report Selection...**

**Selection Criteria...**

Date Range      On or Since : 1 /05/2008  
 (and)  
 On or Before : 30/05/2008

Entry Number

Filename       Return all 'daughter' plate matches

User

OK      Cancel

**Figure 51: Audit Trail Report Selection Window.**

In this window, choose one of the fields and specify a value and then hit **OK** to bring up the search results. The four search criteria are:

- Date Range: List the changes made between two date periods.
- Entry Number: List the changes made on a specific entry.
- Filename: List the changes made on a specific file (Checking 'Return all daughter plate matches' box will give you all the daughter plates created from the filename specified).
- User: List the changes made by a specific user.



### **5.13.2 Material Summary Report**

Please refer to section 5.12.5 for explanation of the material summary report.

## Email Support

---

If you are experiencing troubles using FastTRACK<sup>®</sup> or you have a technical issue you'd like to resolve, you can email FastCAM<sup>®</sup> technical support by using the built-in email function. This functionality is accessed from the **HELP** -> **Email Support** menu.

**Email Support** allows the user to send an email and automatically attach important configuration files within the email. These configuration files help the technicians to troubleshoot any technical issues.

Upon first time use, the user is prompted to enter the following information about the company and its machine. This information will be saved and is not required to be entered the next time.

**Enter Required Information...**

**User Information ...**

**Company Name :** [Your Company Name]

**Contact Name :** [Your Name]

**Email Address :** [email@email.com.au]

**Position :** [Your Position]

**Address :** [Address 1]

**Address :** [Address 2]

**Country :** [ ]

**Optional Information ...**

Machine Brand : [ ]

Controller Model : [ ]

Machine Supplier : [ ]

**Processes**

Oxy       Waterjet

Plasma       Punch

Laser       Marker


I would like to receive FastCAM newsletters.

**NOTE: BOLD items are required.**

OK

**Figure 52: Enter service email information.**

Once you have filled out the basic information, you'll be asked to enter a description for your service enquiry. Complete the '**User Information**' and '**Details of Problem**' section please complete this section to the best of your knowledge, and this will help the technical support team to identify your problem.



**Email Support ...**

**User Information ...**

Company Name : Your Company Name

Contact Name : Your Name

Email Address : name@companyname.com

**Details of Problem ...**

Subject : \_\_\_\_\_

Please describe your problem ...

**Attachments...**

Attach

Please attach any files that will help in resolving your problem.


Details Send Cancel

**Figure 53: Enter service inquiry information.**

### Setting up Service Email:

In order for you to use the service email feature, you must set up your email service client upon the first time:

1. If you are using Microsoft Outlook as the email client, then check the **OUTLOOK** radio button. This will allow you to send the service email via Outlook. When you have finished the problem description section and clicked the '**Send**' button, you'll be directed to Outlook where the email can be sent from.
2. If you are using other email client, please enter the server mail client name and LEFT click OK to finish (as shown in the screenshot below).
3. And if you do not have an internet connection to send email, you have the option to save the email and its attachments onto your local computer. The saved file is a compressed ZIP file, and the user can take this file and send it at a later time.



**Figure 54: Selecting email client.**

## **International Offices**

---

Customers can obtain additional information on the FastCAM® product range by contacting your Local Reseller or from any of our International Offices. They offer high quality and expert service.

The address of our internet site is

**<http://www.fastcam.com>**

### **North America / Europe:**

#### **FASTCAM Inc:**

8700 West Bryn Mawr,  
Suite 800 South

Chicago 60631-3507 USA

Tel: (312) 715 1535

Fax: (312) 715 1536

Email: [fastcam@fastcam.com](mailto:fastcam@fastcam.com)

### **Australia:**

#### **FASTCAM Pty Ltd**

96 Canterbury Rd,  
Middle Park 3206  
Victoria, Australia

Tel: (61) 3 9699 9899

Fax: (61) 3 9699 7501

Email: [fastcam@fastcam.com.au](mailto:fastcam@fastcam.com.au)

### **China:**

#### **FASTCAM China**

No34, 377 Chenhui Rd  
Zhangiang High Tech  
Pudong, Shanghai 201203 China

Tel: (8621) 5080 3069

Fax: (8621) 5080 3071

Email: [fastcam@fastcam.cn](mailto:fastcam@fastcam.cn)

**Or Contact your local Reseller:**



# Index

---

## A

Add Branch Locations, 26  
 Adding a plate, 51  
 Adding Remnant Plate, 53  
*administrator*, 15  
 All Plate, 67  
 Audit Trails Report, 69

## B

Backup your configuration file, 44  
 Branch Locations, 25  
 Browser, 28  
 Browsing Plates, 49

## C

Clear LOCKS, 65  
 Colours, 38  
 Column Text, 42  
 Configuration, 39  
 Current Plate, 67

## D

Database Configuration, 17  
 Database Manager, 28  
 Deleting a plate, 53  
 Deletion Password, 37

## E

Edit Plate, 56  
 Edit Plate Data, 55  
 EMAIL SUPPORT, 73  
 Estimator, 28

## F

FastCAM, 7  
 FastCAM editor, 35

FastLOC dongle, 13  
 FastNEST, 7  
 File Export, 34  
 File Menu, 47

## H

Hardware Requirements, 9

## I

Importing an existing database, 18  
 Inactive Small Plates, 63  
 initial configuration, 25  
 INTRODUCTION, 7

## L

Locate Faults, 63  
 Locations, 25

## M

Manager, 28  
 Material Summary, 72  
*Material.DAT*, 44

## N

Next Plate, 60

## O

Options, 33

## P

Page Setup, 69  
 Paper Setup, 68  
 Pervasive database, 17  
 Pervasive ODBC Engine Interface', 21  
 Plate Database List, 47  
 Plate information, 48

Plate Name Prefix, 35  
Plate Name Suffix, 36  
Plate search filters, 48  
Plate Selection Window, 49  
platesdb, 23  
Previous Plate, 60  
Printing, 66  
Printing Option, 38

## Q

Quick Search, 61

## R

Reports, 69  
Restoring your old database, 44  
Rotate Plate, 60

## S

Search by Entry Number, 62  
Search by Name, 62  
Search First Plate, 62  
Search for Today's Entry, 63  
Search Last Plate, 62  
Search Plate, 61  
Selected plate Preview., 48

Setup Branch Locations, 26  
Setup Location, 31  
Setup Supplier, 30  
Setup Users, 28  
*SETUP.DAT*, 39  
Shortcut Icons, 47  
Show Cost, 67  
*Show Original Plate*, 50  
*Show Text*, 50  
Software Requirements, 9  
**Summary Report**, 67  
Suppliers, 25

## T

The plate list, 49

## U

Update Areas, 63  
UPGRADING, 44  
User Registration, 29  
Users, 25

## W

Windows, 9